How do I edit channel order with Hyper Media Center 3.6?

Couple of extra buttons (blue text) has been added to the main TV control bar.

TV Control Bar

	Stop		Pause		Backward
	Forward		Time-Shifting		Capture
	Snapshot		Teletext		Subtitle
	Channel Preview		SAP		Previous Channel
	Next Channel		Volume Down		Mute
	Volume Up		Switch Mode		Switch Channel List Mode
	My Favorite Channel List		Add channel into My Favorite Channel List		Remove channel from My Favorite Channel List

To edit channel order, select got to home menu, select **“TV” → “Setting”**

Click on **"Edit Channels"**

Note: You have to run **"Scan Channel"** at least once before you can edit channel list.

Here you'll see all the scanned channels. Mouse over any of them and you'll see four shortcut options appear as below circled in red.

- Allows you to delete this channel from the list
- Allows you to renew this channel from the list
- Allows you to add this channel to the “favorite channel list”. Once the channels has been added, you’ll see a start next to channel number.
- Allows you to change channel order

Remember to click on “Yes” when exiting the channel edit window.

- To view your favorite channel list, make sure the is shown on the TV control bar. To see all channels, click on it again until is shown.
- You can also add new channels to My Favorite list by click on the button on the TV control bar